

Driver installation procedure for the second and following printers

◆ Check if a printer driver called “NII ExD NP-3511” is installed (First printer).




- ◆Connect USB cable to USB port on PC side (Other ports than the port used for the first printer).
- ◆Printer driver “NII ExD NP-211” is installed.




- ◆Select printer driver “NII ExD NP-211” and “Printer Properties” after right-clicking.




◆Select “Detailed setting” tab and click “New driver”.




◆Click "Next".




◆Click "Have Disk".




◆Click "Browse" button.




◆ Click select the file “NExD.inf” under the folder “InstallFile” of “NExD” printer driver install media (NExD1.0.4.0_20110204) and click “Open”.




◆ Click “OK” if the file path of “Copy manufacturer’s files from” is the same as where the file “NExD.inf” is stored.




◆Select “NII ExD NP-3511” and click “Next”.




◆Click "Finish".



◆ Check that “Driver” is “NII ExD NP-3511” and click “Apply”.



◆Click "OK".



◆ If a printer driver becomes “NII ExD NP-3511”, the installation is completed.

