

How to set Windows Firewall when using Ex driver (Windows XP/7/8)


2012 / 12 / 07 Edition 1.0

Windows Firewall setting

When Firewall is valid, permission of specific program is required when TCP/IP connecting. Please set Firewall by the following steps.

(Explanation on this guide is with the screen of Windows7.)


1. Open [Control panel] and click [System and Security].



2. Click [Allow a program through Windows Firewall].



3. Press [Allow other applications] after pressing [Change setting].



4. Press [Browse], and assign [C:¥Windows¥System32¥NExStatusSV.exe].
When assignment is done, press [add].
When setting is done, please reboot machine.

